


Wiring Diagram



Notes: Take your smartphone to the light switch when you are configuring.

Make sure you have at least 50% Wifi signal.

Manual Override

The switch Dimmer terminal reserves the access of manual override function for the end-user to switch on/off, or adjust the light level by push-switch.


- * Short Push (<1s): permanent on/off function; can also be configured to recall scene selection
- * Long Push (>1s): adjust the brightness level by turning the light up or down.

Notes:


- 1) Both the adjustment on App and push switch can overwrite each other, the last adjustment remains in memory.
- 2) The switch functions are configured in the App.
- 3) The "S" terminals may be left unconnected if no manual control is required.

Placement Guide and Considerations

Device to Device Placement



⚠ Metals, and other Metalsaterials will reduce the range



⚠ Strong signal sources such as WiFi routers and microwave ovens will affect th range